

### Instructions for fitting RA10 Fridge to Thomson Glennevis

- 1) Remove sink and top.
- 2) Remove sink door.
- 3) Remove sink flap.
- 4) Cut sink flap in line with drawers / edge of sink.
- 5) Remove aluminium plinth.
- 6) Remove rail in line with door opening.
- 7) Extend rail.
- 8) Fit aluminium box L/H side sink.
- 9) Fit 1/2" ply platform 2 3/8" from floor and cover with aluminium.
- 10) Fit Plastic elbow on waste and 5" plastic pipe in elbow, connect plastic pipe to hoses down back of fridge.
- 11) Fit 1/4" pipe, connect to main tap. Place in secure position.
- 12) Fit metal feet on front plastic feet.  
Bolt into leg, screws into front rail.  
Connect 16" - 1/4" pipe into back of fridge.
- 13) Install: Place fridge in position, mark hole for flue, cut out, place flue connector on fridge, cut pipe to suit from outside, fit loose plate on inside pipe plate on outside with cover plate and screw inside and out.
- 14) Connect 1/4" pipe from fridge to tap and secure fridge.
- 15) Fit Dorset 40 Vent above fridge.

