

Measuring for an awning

After searching through various publications which have references to Thomson Caravans I have still not found the exact size quoted for an awning for the Thomson Glen or any other Thomson caravan!

Hopefully this will help you to determine the size you need.

Measure up!



How to check the size.

You can check that the size is correct by finding out your 'A' measurement, as follows.

1. Site the caravan on level ground.
2. Now measure from ground level at the most forward point of the awning channel, right around the channel to its most rearward point, and then down to the ground. (This channel runs along the top and sides of the door side of the tourer.)
3. The start and finish points should be 30cm in front of and 30cm behind where the channel would reach if it extended down to the ground.

**Copyright © 2000 -2007 'Thomson Caravans History & Information'
Disclaimer**

The information provided on this Website site is offered with no warranty as to the authenticity, suitability or competence of the individual, company or service quoted here in. The Website shall not be liable for any damage or difficulty, direct or indirect, arising from utilisation of the information contained within these pages. Thomson T-Line History & Information is not responsible for the content of external websites.